

CLIP ON INSTRUCTIONS

**TO BE INSTALLED BY A CERTIFIED MECHANIC ONLY
FOR RACE USE ONLY**

1. These clip ons are not OEM replacement parts. Vortex clip ons are for race use only.
2. Remove old clip ons and clean mounting areas free of grime, dirt, etc.
3. Install both collars and snug screws.
4. Install handlebar tubes and adjust both bodies to desired angle. Ensure that bars are in a position that will not interfere with turning.
5. Tighten bodies to fork legs.
6. Adjust handlebar tubes to desired length and tighten.
7. Turn steering from lock to lock and be sure there are no obstructions when doing so.
8. You may need to drill small hole(s) in the throttle and/or clutch side handlebar tube(s) for the control switch housing.
9. Install controls and check again to make sure there are no obstructions when turning from lock to lock.
10. When all steps are complete, you're ready to ride. Always check bolts before riding to ensure they are tight.

* HANDLEBAR TUBES ARE SOLD INDIVIDUALLY FOR INEXPENSIVE REPLACEMENT



Questions?

Call 800.440.3559

VORTEX
VORTEXRACING.COM