

RS184 INSTRUCTIONS

TO BE INSTALLED BY A CERTIFIED MECHANIC ONLY | FOR RACE USE ONLY


BRAKE SIDE EXPLODED VIEW

FOR: BMW S1000RR 15-16



INDEX

-  Lubricate
-  Thread Lock
-  Use Factory Piece



RS184 INSTRUCTIONS

TO BE INSTALLED BY A CERTIFIED MECHANIC ONLY | FOR RACE USE ONLY

SHIFT SIDE EXPLODED VIEW

FOR: BMW S1000RR 15-16



INDEX

-  Lubricate
-  Thread Lock
-  Use Factory Piece

